



» APPLICATION BULLETIN

Mevopur™ Healthcare Colorants and Formulations and Mevopur™ Healthcare Functional Additives for In Vitro Diagnostic Devices

Diagnostic devices and consumables, now more than ever, play a vital role in delivery of safe treatments. Fast, accurate and reliable results aid medical professionals to understand the illness and develop the strategy for an effective treatment. New innovations in diagnostic equipment such as improvement in laboratory automation and self-testing devices/POCT (Point-of-Care Testing) diagnostics require increased reliability.

Plastic materials offer opportunities and play an increasingly vital role: colors aid identification and automated laboratory processes while functional additives expand the usable property window of the polymer in areas such as surface chemistry or oxygen protection. Furthermore, designers, quality, and regulatory specialists face new compliance challenges as regulations such as the In Vitro Diagnostics Regulation (IVDR) EU2017/746 are tightened and impact of reclassifications come into force.

KEY CHARACTERISTICS

- Manufactured at four ISO 13485 certified manufacturing sites, providing global consistency and increased security of supply
- Documented change control beyond CAS number, reducing risk of change

- Non-phthalate and formulated without animal-derived substances
- Available as concentrates or ready-to-use formulations in a wide range of polymers
- Functionality and color can be combined in one product for convenience

REGULATORY SUPPORT

- Raw materials tested to:
 - ISO 10993-1 and USP <87> <88> biological evaluation
 - European Pharmacopeia 3.1.3/3.1.5 (polyolefin)
 - USP <661.1> (polyethylene)
 - ICH Q3D elemental impurities
- Registered Drug Master File (Type III) and/or Device Master File
- Documentation support for approval or transition to comply with (new) regulations such as IVDR

FUNCTIONALITY	TARGET APPLICATIONS	BLOOD COLLECTION	REAGENT CONTAINERS/ KITS	PIPETTE/ LABWARE	SELF-TESTING/ POCT	INSTRUMENT/ ACCESSORIES
Colorants for coding for lab automation/ identification	Wide range of colors in various polymers, available in ready-to-use formulation or concentrate adapted to your process	✓	✓		✓	✓
Colors – low migration/ interference	Ready-to-use formulation to avoid interference with analytical tests; extractable metal data	✓	✓		✓	
Colors – biologically evaluated	Reduced risk of non compliance to current and proposed regulations such as IVDR	✓	✓	✓	✓	
Color in PP, ABS, PC and high temperature polymers with UL listings	Ready-to-use solutions/concentrates supporting Underwriters Laboratory requirements of electric enclosures				✓	✓
Antistatic for PP, ABS, PC/ABS	Permanent/non-migrating ready-to-use formulation; fast decay time independent of % relative humidity				✓	✓
Clarifying PP	Sorbitol-free, minimizing potential migration	✓		✓		
Laser marking for UDI replacing ink printing/labels	Activation of the polymer to laser energy give high contrast solvent-free, high speed identification	✓	✓		✓	✓
Laser welding for fast, reliable assembly of a range of polymers	Custom concentrates and ready-to-use formulations for optically transparent and opaque colors while allowing laser transmission/absorption		✓		✓	✓
Nucleation of semicrystalline polymers e.g. HDPE, PP, POM	Fast acting new generation nucleant for PE and PP; improved dimensional stability, thermal and mechanical properties	✓				
Protection from moisture for improved barrier	Reduced Moisture Vapor Transmission Rate (MVTR) HDPE ready-to-use formulation; moisture absorbing concentrates		✓		✓	
Protection from oxygen scavenging in PET	Reduced transmission of oxygen vacuum loss in BCT (blood collection tubes) and protect reagents from oxygen degradation	✓	✓			
Protection from UV in transparent containers (PP, PE, PETG, COP)	UV blocking in 290–450nm with no impact on clarity; protection of light sensitive reagents		✓	✓	✓	✓

Healthcare use limitations apply—see below.

1.844.4AVIENT
www.avient.com



Copyright © 2022, Avient Corporation. Avient makes no representations, guarantees, or warranties of any kind with respect to the information contained in this document about its accuracy, suitability for particular applications, or the results obtained or obtainable using the information. Some of the information arises from laboratory work with small-scale equipment which may not provide a reliable indication of performance or properties obtained or obtainable on larger-scale equipment. Values reported as “typical” or stated without a range do not state minimum or maximum properties; consult your sales representative for property ranges and min/max specifications. Processing conditions can cause material properties to shift from the values stated in the information. Avient makes no warranties or guarantees respecting suitability of either Avient’s products or the information for your process or end-use application. You have the responsibility to conduct full-scale end-product performance testing to determine suitability in your application, and you assume all risk and liability arising from your use of the information and/or use or handling of any product. AVIENT MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, either with respect to the information or products reflected by the information. This literature shall NOT operate as permission, recommendation, or inducement to practice any patented invention without permission of the patent owner.

Avient is committed to the needs of our healthcare customers. As part of our commitment, we publish Avient’s Mevopur™ product policy and use limitations to assist customers in their product selection.

It is the responsibility of the medical device manufacturer and the person placing the medical device on the market to ensure compliance of the medical device with all applicable laws and regulations, including the suitability of all raw materials and components used for its manufacture.

Please be aware that there are certain applications Avient’s Mevopur products have not been designed for, nor are they promoted or intended for use in: including, but not limited to long-term or permanent implants, birth control devices, or plastic surgery.

For more detailed information on Mevopur uses and restrictions see www.avient.com/healthcare-use-limitations-mevopur-products or contact your Avient sales representative.